

CP Applicator

to fit 20mm exit shaft

Stock Code: **CP-AP-HO/20-FP**

Shaft Size: **20mm Exit Shaft**

Top Shaft Outer Diameter: **50mm**

Bottom Shaft Outer Diameter: **51mm**

SETTINGS



1x Orange Female Component:

used to crease light material (100-150gsm)

1x Blue Female Component:

used to crease medium material (150-220gsm)

1x Yellow Female Component:

used to crease heavy material (220-350gsm)

Perforating Blades:

17 TPI (**MPB-17/30mm**) (250/280-350gsm)

to be used with the **Blue Nylon Sleeve**

17 TPI (**MPB-17/30mm**) (170-250/280gsm)

to be used with the **Black Nylon Sleeve**

25 TPI (**MPB-25/30mm**) (100-170gsm)

to be used with the **Black Nylon Sleeve**

52 TPI (**MPB-52/30mm**) (65-100gsm)

to be used with the **Black Nylon Sleeve**

12 TPI (**MPB-12/30mm**) (optional)

72 TPI (**MPB-72/30mm**) (optional)

2x Black Gripper Bands (M-51):

used to feed and support material through device

2x Orange Gripper Crease (M-50):

used to crease material weight between 100-200gsm

2x Blue Gripper Crease (M-49):

used to crease material weight between 200-270gsm

2x Yellow Gripper Crease (M-48):

used to crease material weight between 250-350gsm

1x Extraction Tool:

used to remove gripper crease from gripper crease holder

Contents of Package

1x Male Blade Holder:

used to hold the perforating blade and gripper holder whilst material is fed through

2x Female Nylon Sleeve Holder:

used to secure nylon during perforating process

2x Black Nylon Sleeve (CP-NY/SL-HO):

used on light/medium weight stocks (65-250/280gsm), to allow sufficient blade pressure onto material during perforating process

2x Blue Nylon Sleeve (CP-NY/SL-HO-B):

used on heavier stocks (250-280gsm upwards), allowing sufficient blade pressure onto material

1x Gripper Crease Holder:

used to hold gripper crease into position during creasing process

1x Spacer:

used to replace gripper crease holder during perforating-only process

